

Building embedded systems using Elixir

An introduction to Nerves and Phoenix Framework

Milton Mazzarri

[milmazz](#) @ [Twitter](#) [GitHub](#) [LinkedIn](#)

Jul 17, 2019

Houston Functional Programmers Group

Introduction

Goals

- Introduction to Elixir and Nerves
- Boot a Raspberry Pi to an IEx prompt
- Boot a Raspberry Pi 3 B+ to an IEx prompt

Definitions

Nerves

Nerves defines a new way to build embedded systems using Elixir. It's specifically designed for embedded systems, not desktop or server systems. Nerves is composed by three parts:

Platform a customized, minimal Buildroot-derived Linux that boots directly to the BEAM VM

Framework ready-to-go library of Elixir modules to get you up and running quickly

Tooling powerful command-line tools to manage builds, update firmware, configure devices, and more

Nerves

Nerves defines a new way to build embedded systems using Elixir. It's specifically designed for embedded systems, not desktop or server systems. Nerves is composed by three parts:

Platform a customized, minimal Buildroot-derived Linux that boots directly to the BEAM VM

Framework ready-to-go library of Elixir modules to get you up and running quickly

Tooling powerful command-line tools to manage builds, update firmware, configure devices, and more

Nerves

Nerves defines a new way to build embedded systems using Elixir. It's specifically designed for embedded systems, not desktop or server systems. Nerves is composed by three parts:

Platform a customized, minimal Buildroot-derived Linux that boots directly to the BEAM VM

Framework ready-to-go library of Elixir modules to get you up and running quickly

Tooling powerful command-line tools to manage builds, update firmware, configure devices, and more

Host

The computer on which you are editing source code, compiling, and assembling firmware

The platform for which your firmware is built (for example, Raspberry Pi, Raspberry Pi 2, or Beaglebone Black)




Figure 1: Raspberry Pi 3 Model B+

Toolchain

The tools required to build code for the target, such as compilers, linkers, binutils, and C runtime

A lean Buildroot-based Linux distribution that has been customized and cross-compiled for a particular target

Firmware bundle

A single file that contains an assembled version of everything needed to burn firmware

Firmware image

Built from a firmware bundle and contains the partition table, partitions, bootloader, etc.

Nerves overview

Batteries included




Figure 2: Nerves Overview

Supported targets and systems


Target	System	Tag
Raspberry Pi A+, B, B+	nerves_system_rpi	rpi
Raspberry Pi Zero and Zero W	nerves_system_rpi0	rpi0
Raspberry Pi 2	nerves_system_rpi2	rpi2
Raspberry Pi 3 B, B+	nerves_system_rpi3	rpi3
BeagleBone Black, BeagleBone Green, BeagleBone Green Wireless, Pocket-Beagle	nerves_system_bbb	bbb
Generic x86_64	nerves_system_x86_64	x86_64

Artifacts

- application name

Example

nerves_system_rpi - portable - 1.7.2 - ED1F541 .tar.gz




- host
- version
- checksum

Artifacts

- application name

Example

nerves_system_rpi - portable - 1.7.2 - ED1F541 .tar.gz



- host
- version
- checksum

Artifacts

- application name

Example

nerves_system_rpi - portable - 1.7.2 - ED1F541 .tar.gz

- host
- version
- checksum

Artifacts

- application name

Example

nerves_system_rpi - portable - 1.7.2 - ED1F541 .tar.gz

- host
- version
- checksum

tar files ~/.nerves/dl

uncompressed files ~/.nerves/artifacts

Getting started

mix help nerves.new

Creates a new Nerves project

```
mix nerves.new PATH [--module MODULE] [--app APP]
                  [--target TARGET] [--cookie STRING]
```

The project will be created at PATH. The application name and module name will be inferred from PATH unless --module or --app is given.

An --app option can be given in order to name the OTP application for the project.

A --module option can be given in order to name the modules in the generated code skeleton.

A --target option can be given to limit support to one or more of the officially Nerves systems. For a list of supported targets visit <https://hexdocs.pm/nerves/targets.html#supported-targets-and-systems>

A --cookie options can be given to set the Erlang distribution cookie in vm.args. This defaults to a randomly generated string.

Generate a project without nerves_init_gadget support by passing --no-init-gadget.

mix help nerves.new

Creates a new Nerves project

```
$ mix nerves.new blinky  
$ # Is equivalent to:  
$ mix nerves.new blinky --module Blinky
```

Generate a project that only supports Raspberry Pi 3

```
$ mix nerves.new blinky --target rpi3
```

Generate a project that supports Raspberry Pi 3 and Raspberry Pi Zero

```
$ mix nerves.new blinky --target rpi3 --target rpi0
```

Generate a project without nerves_init_gadget

```
$ mix nerves.new blinky --no-init-gadget
```

Demo

Recap

Our first Nerves project

Example

```
$ mix nerves.new say --target rpi --cookie hello
* creating say/config/config.exs
* creating say/lib/say.ex
* creating say/lib/say/application.ex
* creating say/test/test_helper.exs
* creating say/test/say_test.exs
* creating say/rel/vm.args
* creating say/rootfs_overlay/etc/iex.exs
* creating say/.gitignore
* creating say/.formatter.exs
* creating say/mix.exs
* creating say/README.md

Fetch and install dependencies? [Yn] Y
* running mix deps.get
Your Nerves project was created successfully.
```

Our first Nerves project

You should now pick a target. See

<https://hexdocs.pm/nerves/targets.html#content>

for supported targets. If your target is on the list, set `MIX_TARGET` to its tag name:`

For example, for the Raspberry Pi 3 you can either

```
$ export MIX_TARGET=rpi3
```

Or prefix ``mix`` commands like the following:

```
$ MIX_TARGET=rpi3 mix firmware
```

If you will be using a custom system, update the ``mix.exs`` dependencies to point to desired system's package.

Now download the dependencies and build a firmware archive:

```
$ cd say
```

```
$ mix deps.get
```

```
$ mix firmware
```

If your target boots up using an SDCard (like the Raspberry Pi 3), then insert an SDCard into a reader on your computer and run:

```
$ mix firmware.burn
```


Plug the SDCard into the target and power it up. See target documentation above for more information and other targets.

Our first Nerves project

Example

```
$ cd say  
$ set -x MIX_TARGET rpi  
$ mix deps.get
```

Project structure




- 1 Mix Project definition
- 2 Application definition
- 3 Main module
- 4 Configuration for all targets
- 5 Unit test suite
- 6 Dependencies archives
- 7 Releases configuration
- 8 The code loaded from here will be evaluated in the IEx session context of the target.

Project structure



- 1 Mix Project definition
- 2 Application definition
- 3 Main module
- 4 Configuration for all targets
- 5 Unit test suite
- 6 Dependencies archives
- 7 Releases configuration
- 8 The code loaded from here will be evaluated in the IEx session context of the target.

Project structure




- ❶ Mix Project definition
- ❷ Application definition
- ❸ **Main module**
- ❹ Configuration for all targets
- ❺ Unit test suite
- ❻ Dependencies archives
- ❼ Releases configuration
- ❽ The code loaded from here will be evaluated in the IEx session context of the target.

Project structure




- ❶ Mix Project definition
- ❷ Application definition
- ❸ Main module
- ❹ Configuration for all targets
- ❺ Unit test suite
- ❻ Dependencies archives
- ❼ Releases configuration
- ❽ The code loaded from here will be evaluated in the IEx session context of the target.

Project structure



- 1 Mix Project definition
- 2 Application definition
- 3 Main module
- 4 Configuration for all targets
- 5 Unit test suite
- 6 Dependencies archives
- 7 Releases configuration
- 8 The code loaded from here will be evaluated in the IEx session context of the target.

Project structure




- ① Mix Project definition
- ② Application definition
- ③ Main module
- ④ Configuration for all targets
- ⑤ Unit test suite
- ⑥ Dependencies archives
- ⑦ Releases configuration
- ⑧ The code loaded from here will be evaluated in the IEx session context of the target.

Project structure



- ❶ Mix Project definition
- ❷ Application definition
- ❸ Main module
- ❹ Configuration for all targets
- ❺ Unit test suite
- ❻ Dependencies archives
- ❼ Releases configuration
- ❽ The code loaded from here will be evaluated in the IEx session context of the target.

Project structure



- ① Mix Project definition
- ② Application definition
- ③ Main module
- ④ Configuration for all targets
- ⑤ Unit test suite
- ⑥ Dependencies archives
- ⑦ Releases configuration
- ⑧ The code loaded from here will be evaluated in the IEx session context of the target.

mix.exs - Mix Project definition

```
defmodule Say.MixProject do
  use Mix.Project

  @app :say
  @version "0.1.0"
  @all_targets [:rpi]

  def project do
    [
      app: @app,
      version: @version,
      elixir: "~> 1.9",
      archives: [nerves_bootstrap: "~> 1.6"],
      start_permanent: Mix.env() == :prod,
      build_embedded: true,
      aliases: [loadconfig: [&bootstrap/1]],
      deps: deps(),
      releases: [{@app, release()}],
      preferred_cli_target: [run: :host, test: :host]
    ]
  end

  def bootstrap(args) do
    Application.start(:nerves_bootstrap)
    Mix.Task.run("loadconfig", args)
  end
end
```

mix.exs - Mix Project definition

```
def application do
  [
    mod: {Say.Application, []},
    extra_applications: [:logger, :runtime_tools]
  ]
end

defp deps do
  [
    # Dependencies for all targets
    {:nerves, "~> 1.5.0", runtime: false},
    {:shoehorn, "~> 0.6"},
    {:ring_logger, "~> 0.6"},
    {:toolshed, "~> 0.2"},
    # Dependencies for all targets except :host
    {:nerves_runtime, "~> 0.6", targets: @all_targets},
    {:nerves_init_gadget, "~> 0.4", targets: @all_targets},
    # Dependencies for specific targets
    {:nerves_system_rpi, "~> 1.8", runtime: false, targets: :rpi},
  ]
end
```

Unit tests

Example

```
# test/say_test.exs
defmodule SayTest do
  use ExUnit.Case
  doctest Say

  test "greets the world" do
    assert Say.hello() == :world
  end
end
```

Example

```
# test/test_helper.exs
ExUnit.start()
```

Example

```
# lib/say.ex
defmodule Say do
  @moduledoc """
    Documentation for Say.
  """

  @doc """
    Hello world.
  """
   Examples

    iex> Say.hello
    :world

  """
  def hello do
    :world
  end
end
```

Running unit tests on host

Example

```
$ env MIX_TARGET=host mix test
==> nerves
Compiling 37 files (.ex)
Generated nerves app
==> toolshed
Compiling 9 files (.ex)
Generated toolshed app
==> ring_logger
Compiling 4 files (.ex)
Generated ring_logger app
==> shoehorn
Compiling 8 files (.ex)
Generated shoehorn app
==> say
Compiling 2 files (.ex)
Generated say app

..

Finished in 0.03 seconds
1 doctest, 1 test, 0 failures
```


Mix Tasks

Mix Task	Description
<code>mix firmware</code>	Build a firmware image for the selected target platform
<code>mix firmware.burn</code>	This task calls <code>mix firmware</code> and <code>mix burn</code> to burn a new firmware to a SDCard
<code>mix nerves.info</code>	Prints nerves system information
<code>mix burn</code>	Writes the generated firmware image to an attached SDCard or file
<code>mix firmware.image</code>	Create a firmware image file that can be copied byte-for-byte to an SDCard or other memory device

nerves_init_gadget

The nerves_init_gadget project provides the basics for getting started with Nerves. This includes bringing up networking, over-the-air firmware updates and many other little things that make using Nerves a little better.

 [**nerves-project/nerves_init_gadget**](https://github.com/nerves-project/nerves_init_gadget)

Configuring nerves_init_gadget

Example

```
config :nerves_init_gadget,  
ifname: "eth0",  
address_method: :dhcpcd,  
mdns_domain: "nerves.local",  
node_name: node_name,  
node_host: :mdns_domain
```

Listing 1: config/target.exs

Our first Nerves project

Burn firmware

Example

```
$ mix firmware  
$ # Insert SD Card  
$ mix firmware.burn  
$ ssh nerves.local
```

Our first Nerves project

Start a SSH session

```
$ ssh nerves.local
```

```
Interactive Elixir (1.9.0) - press Ctrl+C to exit (type h() ENTER for help)  
Toolshed imported. Run h(Toolshed) for more info  
RingLogger is collecting log messages from Elixir and Linux. To see the  
messages, either attach the current IEx session to the logger:
```

```
    RingLogger.attach
```

or print the next messages in the log:

```
    RingLogger.next
```

```
iex(say@nerves.local)1>
```

Our first Nerves project

Trying out some things on the **target**:

Example

```
iex(say@nerves.local)1> Say.hello()  
:world  
iex(say@nerves.local)2> cmd("date")  
Thu Jan  1 00:04:21 UTC 1970  
0  
iex(say@nerves.local)4> exit  
Connection to nerves.local closed.
```

To close our SSH session we use the escape sequence `~.` or `exit/0` (provided by the **Toolshed** package)

Toolshed

Toolshed adds a number of commands to the IEx prompt to make working at the console more enjoyable. It's an experiment in aggregating code snippets from projects into one place.

 [**fhunleth/toolshed**](https://github.com/fhunleth/toolshed)

Some commands provided by Toolshed

command	description
cmd	run a command and print out the output
top	get a list of the top processes and their OTP applications based on CPU and memory
exit	exit an IEx session (useful over ssh)
tree	list directory contents as a tree
save_term/load_term	save and load Elixir terms to files
tping	check if a remote host is up (like ping, but uses TCP)
ifconfig	list network interfaces
lsusb	list USB devices

To get the complete list of commands execute: `iex> h Toolshed`

nerves_time

Nerves.Time keeps the system clock on Nerves devices in sync when connected to the network and close to in sync when disconnected. It's especially useful for devices lacking a Battery-backed real-time clock and will advance the clock at startup to a reasonable guess.

 [fhunleth/nerves_time](https://github.com/fhunleth/nerves_time)

Introducing nerves_time

Example

```
$ mix hex.info nerves_time
```

Keep time in sync on Nerves devices

Config: {:nerves_time, "~> 0.2.1"}

Releases: 0.2.1, 0.2.0, 0.1.0

Licenses: Apache-2.0

Links:

GitHub: https://github.com/fhunleth/nerves_time

Add nerves_time as dependency

```
# Dependencies for all targets except :host
{:nerves_runtime, "~> 0.6", targets: @all_targets},
{:nerves_init_gadget, "~> 0.4", targets: @all_targets},
{:nerves_time, "~> 0.2", targets: @all_targets},
```

Update dependencies and push changes back

Example

```
$ # Updated dependencies
$ mix deps.get
$ mix firmware.gen.script
Writing upload.sh...
$ # Upload new firmware to nerves.local
$ ./upload.sh
$ ssh nerves.local
```

Running IEx session on target

Example

```
iex(say@nerves.local)1> cmd("date")
```

```
Mon Jul  8 18:11:56 UTC 2019
```

```
0
```

```
iex(say@nerves.local)2> exit
```

```
Connection to nerves.local closed.
```

Introducing a matching error

Example

```
def start(_type, _args) do
  true = false

  # See https://hexdocs.pm/elixir/Supervisor.html
  # for other strategies and supported options
  opts = [strategy: :one_for_one, name: Say.Supervisor]
  children =
    [
      # Children for all targets
      # Starts a worker by calling: Say.Worker.start_link(arg)
      # {Say.Worker, arg},
    ] ++ children(target())

  Supervisor.start_link(children, opts)
end
```

Listing 2: lib/say/application.ex

Running on host

Example

```
$ env MIX_TARGET=host iex -S mix  
Erlang/OTP 22 [erts-10.4.3] [source] [64-bit] [smp:4:4] [ds:4:4:10] [async-  
threads:1] [hipe]
```

Compiling 1 file (.ex)

```
warning: no clause will ever match  
  lib/say/application.ex:9
```

Generated say app

```
**      (Mix)      Could      not      start      application      say:      ex-  
ited in: Say.Application.start(:normal, [])  
      ** (EXIT) an exception was raised:  
          ** (MatchError) no match of right hand side value: false  
              (say) lib/say/application.ex:9: Say.Application.start/2  
                  (kernel) application_master.erl:277: :applica-  
tion_master.start_it_old/4
```

Updating the target anyway

Example

```
$ mix firmware  
$ ./upload.sh
```


Starting a SSH session on target

```
Interactive Elixir (1.9.0) - press Ctrl+C to exit (type h() ENTER for help)
Toolshed imported. Run h(Toolshed) for more info
RingLogger is collecting log messages from Elixir and Linux. To see the
messages, either attach the current IEx session to the logger:
```

```
RingLogger.attach
```

or print the next messages in the log:

```
RingLogger.next
```

```
iex(say@nerves.local)1> Say.hello()
:world
```

Did the failure cause a crash?

The failure indeed caused a crash, but still the application was able to recover. How that internally works?

```
iex(say@nerves.local)2> RingLogger.grep("MatchError")
18:57:09.126 [info] Application say exited: exited in: Say.Application.start(:normal, [])
** (EXIT) an exception was raised:
** (MatchError) no match of right hand side value: true
(say) lib/say/application.ex:9: Say.Application.start/2
(kernel) application_master.erl:277: :application_master.start_it_old/4

:ok
```

Shoehorn

Shoehorn acts as a shim to the initialization sequence for your application's VM. Using Shoehorn, you can ensure that the VM will always pass initialization.

This is especially useful when running Nerves.

 [**nerves-project/shoehorn**](https://github.com/nerves-project/shoehorn)

Shoehorn configuration

Example

```
config :shoehorn,  
init: [:nerves_runtime, :nerves_init_gadget],  
app: Mix.Project.config()[[:app]]
```

Listing 3: config/config.exs

Manually reverting firmware updates

```
iex(say@nerves.local)1> Nerves.Runtime.KV.get_all()  
%{  
  "a.nerves_fw_application_part0_devpath" => "/dev/mmcblk0p3",  
  "a.nerves_fw_application_part0_fstype" => "ext4",  
  "a.nerves_fw_application_part0_target" => "/root",  
  "a.nerves_fw_architecture" => "arm",  
  "a.nerves_fw_author" => "The Nerves Team",  
  "a.nerves_fw_description" => "",  
  "a.nerves_fw_misc" => "",  
  "a.nerves_fw_platform" => "rpi",  
  "a.nerves_fw_product" => "say",  
  "a.nerves_fw_uuid" => "c92646d3-5ed9-5725-f475-6d1d2f9fee61",  
  "a.nerves_fw_vcs_identifier" => "",  
  "a.nerves_fw_version" => "0.1.0",  
  "nerves_fw_active" => "a",  
  "nerves_fw_devpath" => "/dev/mmcblk0",  
  "nerves_serial_number" => ""  
}
```

Uploading changes

```
$ ./upload.sh
```

```
Path: ./_build/rpi_dev/nerves/images/say.fw
```

```
Product: say 0.1.1
```

```
UUID: 22de7e22-2313-5eb4-8786-fe1e2a7e296d
```

```
Platform: rpi
```

```
Uploading to nerves.local...
```

```
Running fwup...
```

```
fwup: Upgrading partition B
```

```
|=====| 100% (23.69 / 23.69) MB
```

```
Success!
```

```
Elapsed time: 16.138 s
```

```
Rebooting...
```

Manually reverting firmware updates

```
iex(say@nerves.local)1> Nerves.Runtime.KV.get_all()  
%{  
  "a.nerves_fw_application_part0_devpath" => "/dev/mmcblk0p3",  
  # ...  
  "b.nerves_fw_application_part0_devpath" => "/dev/mmcblk0p3",  
  "b.nerves_fw_application_part0_fstype" => "ext4",  
  "b.nerves_fw_application_part0_target" => "/root",  
  "b.nerves_fw_architecture" => "arm",  
  "b.nerves_fw_author" => "The Nerves Team",  
  "b.nerves_fw_description" => "",  
  "b.nerves_fw_misc" => "",  
  "b.nerves_fw_platform" => "rpi",  
  "b.nerves_fw_product" => "say",  
  "b.nerves_fw_uuid" => "22de7e22-2313-5eb4-8786-fe1e2a7e296d",  
  "b.nerves_fw_vcs_identifier" => "",  
  "b.nerves_fw_version" => "0.1.1",  
  "nerves_fw_active" => "b",  
  "nerves_fw_devpath" => "/dev/mmcblk0",  
  "nerves_serial_number" => ""  
}
```

```
iex(say@nerves.local)2> Nerves.Runtime.revert()
```

Received disconnect from 172.31.129.157 port 22:11:

Terminated (shutdown) by supervisor

Manually reverting firmware updates

```
iex(say@nerves.local)1> Nerves.Runtime.KV.get_all()  
%{  
  "a.nerves_fw_application_part0_devpath" => "/dev/mmcblk0p3",  
  "a.nerves_fw_application_part0_fstype" => "ext4",  
  "a.nerves_fw_application_part0_target" => "/root",  
  "a.nerves_fw_architecture" => "arm",  
  "a.nerves_fw_author" => "The Nerves Team",  
  "a.nerves_fw_description" => "",  
  "a.nerves_fw_misc" => "",  
  "a.nerves_fw_platform" => "rpi",  
  "a.nerves_fw_product" => "say",  
  "a.nerves_fw_uuid" => "c92646d3-5ed9-5725-f475-6d1d2f9fee61",  
  "a.nerves_fw_vcs_identifier" => "",  
  "a.nerves_fw_version" => "0.1.0",  
  # ...  
  "nerves_fw_active" => "a",  
  "nerves_fw_devpath" => "/dev/mmcblk0",  
  "nerves_serial_number" => ""  
}
```


SD Card partitions

Master Boot Record
Provisioning info
Boot A (FAT32)
Boot B (FAT32)
Root file system A (squashfs)
Root file system B (squashfs)
Application Data (ext4)

ring_logger

RingLogger is an in-memory ring buffer backend for the Elixir Logger with convenience methods for accessing the logs from the IEx prompt.

 [**nerves-project/ring_logger**](https://github.com/nerves-project/ring_logger)

RingLogger use cases

- Get log messages in real-time over remote IEx sessions
- Grep and tail through log messages without setting up anything else
- Keep logs in limited resource environments
- Capture recent log events for error reports

RingLogger usage sample

Example

```
# env MIX\_TARGET=host iex --sname host1 --cookie hello -S mix
iex(host1@heimdallr)1> Logger.add_backend(:console)
{:ok, #PID<0.214.0>}
iex(host1@heimdallr)2> Logger.remove_backend(RingLogger)
:ok
iex(host1@heimdallr)3> require Logger
Logger
iex(host1@heimdallr)4> Logger.info("hello")
15:51:39.866 [info] hello
:ok
iex(host1@heimdallr)5> Logger.add_backend(RingLogger)
{:ok, #PID<0.221.0>}
iex(host1@heimdallr)6> Logger.info("hello")
15:52:01.412 [info] hello

:ok
```

Example

```
# env MIX\_TARGET=host iex --sname host2 --cookie hello --remsh host1
iex(host1@heimdallr)1> RingLogger.attach()
:ok

15:52:01.412 [info] hello
```

Phoenix Demo

 [mobileoverlord/training_kiosk](https://github.com/mobileoverlord/training_kiosk)

Questions?

More information

- nerves-project.org
- embedded-elixir.com
- hexdocs.pm/nerves
- github.com/nerves-project
- github.com/nerves-hub
- elixirforum.com/tags/nerves
- elixir-slackin.herokuapp.com
- github.com/nerves-project/nerves_examples

Thanks!

Slides: speakerdeck.com/milmazz